Poly Edge E500/E550 Quick Reference Guide



1. Handset

Microban® antimicrobial protection helps your handset resist the growth of microbes such as bacteria and mold.

2. Line keys

E500 & E550: 12

Note: Line assignments are limited to 32.

3. Back button

Return to previous screen

4. LED bar: Visual indicator of call & phone status

Incoming call - blinking green

Active call - solid green

All calls on hold/new voicemail - blinking red

Idle mode - blinking yellow

Bluetooth discovery mode on E550 - blue chase animation (E500 does not support Bluetooth.)

- 5. Color display
- b. Pagination key

Used to view additional line screens

7. Softkeys

Context-sensitive keys that change depending on your phone's status

- 8. Home
- 9. Navigation and select buttons
- 10. Voicemail
- 11. Headset
- 12. Speakerphone
- 13. Mute
- 14. Volume

Adjusts volume for handset, headset, speaker and ringer

- 15. Transfer
- 16. Hold



Poly Edge E500/E550 Quick Reference Guide

Place a call

Do one of the following:

- Pick up the handset, enter the number, and press the **send** softkey.
- Press the **speakerphone** or **headset** key, enter the number, and press the **send** softkey.
- Enter the number, press the **dial** softkey then pick up the handset.
- Enter the number and press the **speakerphone** (a) or **headset** (b) key.
- Press the **line key**, enter the number, and press the **send** softkey.
- Press **new call** softkey, enter the number, and press the **send** softkey.

Answer a call

Do one of the following:

- Press the **answer** softkey.
- Press the headset key.
- Press the **speakerphone** (a) key.
- Pick up the handset.

Hold and resume a call

- Hold: Highlight the call and press the hold \ key or hold softkey.
- **Resume**: Highlight the call press the **hold ** key or **resume** softkey.

Conference calls

- 1. On an active call, select the **conference** softkey. The person you are talking to is placed on hold and you receive a dial tone.
- Enter a number, select a contact from the directory, or select a contact from a call list.
- When the contact answers, select the conference softkey to connect all parties.
 - If the contact is not available to join the call, press the cancel softkey to release the contact and return to your original call.

Transferring calls

Attended transfer

- 1. Press and hold the **transfer (-1)** key or **transfer** softkey.
- 2. Choose consultative.
- 3. Dial a number or chose a contact.
- 4. After announcing the caller to your contact, press the **transfer** (key or **transfer** softkey to complete the transfer.

Blind transfer

- 1. Press and hold the **transfer** (+) key or **transfer** softkey...
- Choose blind.
- 3. Enter a number or choose a contact. The call is transferred immediately.

End a call

• Press the **end** softkey.

Forwarding calls

Forward an incoming

- 1. Without answering the call, press the **forward** softkey.
- 2. Enter the number to forward the call.
- 3. Press the **forward** softkey again.

Forward all calls

- 1. Press the **forward** softkey or go to settings > features > forward.
- 2. On the **forwarding type select** screen, select a forwarding type:
 - ALWAYS. Incoming calls are forwarded unconditionally.
 - BUSY. Incoming calls are forwarded when phone is busy.
 - NO ANSWER. Incoming calls are forwarded if not answered after a time. (This is the only option for shared lines)
- 3. Enter a number and press **enable**.
 - If you selected **no answer**, enter the number of rings before the call is forwarded.

Preferences

Ringtone

- 1. Go to menu > settings > basic.
- 2. Press ring type.
- Press the **play** softkey to hear the ringtone (optional) and make your selection.
- 4. Press the **select** softkey to apply the ringtone.

Volume

- Mute: Press the mute softkey or key ②.
- 2. Volume: Press the **volume** key up or down to adjust the volume of the ringer, media, and audio on an active call.

Voicemail

When you have a new voicemail, a message icon is displayed on the home screen, in the status bar, and next to the phone line on the lines screen.

- 1. Go to messages > message center > connect.
- 2. Follow the prompts to access your messages.

Wi-Fi (E550 only)

Enable Wi-Fi

- 1. Go to menu > Wi-Fi or menu > settings > basic > Wi-Fi menu.
- 2. Press the **select** key to enable Wi-Fi, then press **save**.
- Press reboot. After the phone reboots, it can connect to a wireless network.

Connect to a wireless network

- 1. Do one of the following:
 - Press the scan softkey to scan for available networks, select one and enter the network's required security settings.
 - Press the **other** softkey to manually enter network settings, including SSID, security type and password.
- Select connect.

